



cocoon™
4 CAMERA HOME SECURITY SYSTEM
WITH DVR



Getting Started Guide

HE150242
12/2015


- 1.** Connect each of the camera extension cables to the video and power connectors.



- 2.** Connect the other end of the extension cables to the video cable splitter. Connect the splitter to the port marked "VIDEO IN/OUT" on the side of the DVR.



- 3.** Connect the 4-way power splitter to each of the extension cable power plugs.



- 4.** Connect the included HDMI cable to the back of the DVR and connect the other end of the HDMI cable to your monitor or TV.

NOTE: You must switch your TV or monitor to the correct INPUT once the DVR has been powered on. For example, HDMI1



COCOON™

4 CAMERA HOME SECURITY SYSTEM WITH DVR



Getting Started Guide

HE150242
12/2015

- 5.** Connect the mouse to the rear USB port.



- 6.** Connect the power adaptor to the 4-way splitter and plug into an outlet. Switch the outlet on.



- 7.** Connect the remaining power adaptor to the DVR and plug into a mains outlet. Switch the outlet on. The DVR will begin the boot sequence.

NOTE: Both the DVR and cameras operate "always on". To turn the cameras or DVR off, switch off the power adaptors at the power outlet



Tips: Test all connections are working before permanently installing DVR and cameras. Position the DVR in a central location where all 4 cameras will reach. If using the optional networking features make sure the modem is near the DVR